



# OFF LIMITS™

## VOICE VAULT™



Model 74035  
For 1 User / Ages 8 and up  
**INSTRUCTION MANUAL**  
P/N 82385700 Rev.B

Nobody touches your stuff! YOU have the control to protect your stuff from anyone because only your codeword can open it. Keep your stuff protected and OFF LIMITS from anyone!

### GETTING STARTED

#### BATTERY INSTALLATION:

Voice Vault™ is powered by three (3) AAA (LR03) batteries in each unit.


- Using a screwdriver, loosen the screw until the battery compartment door on the back of the power pack can be removed.
- Insert three (3) AAA (LR03) batteries (we recommend alkaline) as indicated inside the battery compartment.
- Replace the battery compartment door and tighten the screw with a screwdriver. Do not over-tighten.

#### ADULT SUPERVISION IS RECOMMENDED WHEN CHANGING BATTERIES.

#### CAUTION:

- As with all small batteries, the batteries used with this product should be kept away from small children who might still put things in their mouths. If a battery is swallowed, consult a physician immediately.
- Be sure you insert the battery correctly and always follow the product and battery manufacturer's instructions.
- Do not dispose of batteries in fire.
- Batteries might leak if improperly installed, or explode if recharged, disassembled or heated.

#### FEATURES:



**ACCESS BUTTON** - Press this button to start the process of entering your codeword.

**E ACCESS LIGHT** - Lights up when it is time to say your codeword.

**SECURITY HI • LO** - Use this button to switch between hi or lo security.


• **Hi Security** - This mode is more sensitive and difficult for anyone to repeat your codeword. This mode should only respond to your voice. Please note, you must make sure you speak your codeword exactly the same way each time.

• **Lo Security** - This mode is less sensitive and easier to use. If someone is able to get in using this mode, switch to the Hi.

**Troubleshooting** - If you are having difficulty gaining access to your Voice Vault™ in Hi Security, please make sure you say your codeword the exact same way each time. If it is still difficult, switch to Lo Security. This mode is less sensitive.

**SET CODEWORD** - Press and hold this button to reset your codeword.

**RESET** - Reset button is located inside battery compartment. Use this button to reset Voice Vault™. Insert a dull, blunt object (like the end of a paper clip) into the reset button hole. **Please note: if you are locked out and cannot remember your codeword reset your Voice Vault™.**



### SET UP

#### 1. RECORDING YOUR CODEWORD

After installing the batteries, you will be prompted to "Enter codeword now". Wait for the green "Access" light to turn ON, then say your chosen codeword into the microphone (MIC). Your codeword can be any word such as FIDO, COOL or anything you want to be.

**NOTE:** If you do not wait until the green light is on, Voice Vault™ will not "hear" your codeword and will prompt you to speak again: "Codeword not identical, enter codeword now." Be sure to speak clearly and say your codeword exactly the same each time.

Voice Vault™ will prompt you to repeat your new codeword again: "Repeat your codeword." If you have spoken your codeword correctly, your new codeword will be accepted: "Codeword authenticated."

#### 2. OPENING YOUR VOICE VAULT™

Press the "Access" button. You will be prompted with "Enter codeword now." Wait for the green "Access" light and then say your chosen codeword clearly into the microphone (MIC). Continue following the voice prompts until your Voice Vault™ opens automatically. Each time you open your Voice Vault™ you will be told if you have had any attempted intruders and how many.

**NOTE:** If you have spoken the wrong codeword, Voice Vault™ will give you a chance to correct yourself. You will be prompted with "Enter codeword now." Wait for the green access light and then speak your chosen codeword clearly into the microphone (MIC). If you say the wrong codeword again, Voice Vault™ will sound the intruder alarm: "Codeword not identical, entry denied."

#### 3. CLOSING YOUR VOICE VAULT™

To close Voice Vault™, you must press the lid all the way down. If a pass code is recorded, you will hear "Armed" and other sound effects to confirm your Voice Vault™ is closed. If you do not hear the word "Armed", your Voice Vault™ is not secure. If a pass code is not recorded, you will only hear sound effects to confirm your Voice Vault™ is closed. Helpful Hint: Make sure you press down firmly on the right side tab of the door to successfully close your Voice Vault™.

#### 4. CHANGING YOUR CODEWORD

From time to time, you may want to change your codeword (especially if you think someone else knows it!)

Open Voice Vault™ using your old codeword. Press and hold the "Set Codeword" button once. You will be prompted to "Enter codeword now." Wait for the green "Access" light to turn on, then say your chosen codeword into the microphone (MIC).

**NOTE:** If you do not wait until the green light is on. Voice Vault™ will not "hear" your codeword and will prompt you to speak again: "Codeword not identical, enter codeword now."

Voice Vault™ will prompt you to repeat your new codeword again: "Repeat codeword now." If you have spoken your new codeword correctly, your new codeword will be accepted: "Codeword authenticated."

**NOTE:** Be sure to speak clearly and say your codeword exactly the same each time.

#### 5. NO CODEWORD

If you do not want to use the codeword function, do not record a codeword in the set up process. To gain access to the Voice Vault™, just press the Access button to open. You may want to use this feature if you are having difficulty opening the Voice Vault™ with your chosen codeword.

#### 6. RESETTING VOICE VAULT™

Press the "Reset" button located in the battery compartment to open your Voice Vault™. Insert a dull, blunt object (like the end of a paper clip) into the Reset "button hole." Voice Vault™ will open and you can reset your codeword.

#### IMPORTANT

**Sometimes, a built-up of static electricity ( from carpets, etc ) may cause the game to stop working. Just reset the game, and it will work again.**

#### MAINTENANCE:

- Handle this device carefully.
- Store this device away from dusty or dirty areas.
- Keep this device away from moisture or extreme temperature.
- Do not disassemble this device. If a problem occurs, press the Reset button, or remove and replace the batteries to reset the device, or try new batteries. If problems persist, consult the warranty information located at the end of this instruction manual.
- Use only the recommended battery type.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Do not use rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Remove any exhausted batteries from the device.
- Do not short-circuit the supply terminals.
- Insert batteries with the correct polarity.

**Please retain this for future reference.**

#### FOR UNITED STATES

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct

the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

#### 90-DAY LIMITED WARRANTY

**(This product warranty is valid in the United States and Canada only)**

Radica Games Limited warrants this product for a period of 90 days from the original purchase date under normal use against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica Games Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

During this 90-day warranty period, the game will either be repaired or replaced (at our option) without charge to the purchaser when returned prepaid with proof of date of purchase to: **Radica USA, Ltd., 13628-A Beta Road, Dallas, Texas 75244, USA.** Please remove the batteries and wrap the unit carefully before shipping. Please include a brief description of the problem along with your return address and mail it postage prepaid.

**IMPORTANT:** Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

#### FOR UNITED KINGDOM

#### PRODUCT WARRANTY

**(This product warranty is valid in the United Kingdom only)**

All products in the **RADICA®** range are fully guaranteed for a period of 6 months from the original purchase date under normal use, against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship.

In the unlikely event that you do experience a problem within the first 6 months, please telephone the UK Technical Support team: **Tel. 0871 222 8278. Calls are charged at 10p per minute and will show up on your standard telephone bill. Helpline hours are 2pm-11pm, Monday to Friday.**

**IMPORTANT:** Always test the product with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

**YOUR STATUTORY RIGHTS ARE NOT EFFECTED.**

Distributed in the U.S. by:  
**RADICA U.S. Ltd.**  
13628-A Beta Road  
Dallas, TX 75244-4510



Distributed in the U.K. by:  
**RADICA U.K. Ltd.**  
The Old Stables, Munns Farm,  
Cole Green, Hertfordshire,  
SG14 2NL, England



**RADICA:®**  
OFF LIMITS AND VOICE VAULT ARE THE  
TRADEMARKS OF RADICA GAMES LTD.  
© 2004 RADICA GAMES LTD.  
PRODUCT SHAPE™  
ALL RIGHTS RESERVED